

Q-Wrap

Self Fusing Drip Tubing Repair Tape

Seals leaky or broken Tubing, Pipe, Fittings, Hoses & More!

Create a Permanent Water and Air-tight Seal • Works on Wet, Dirty or Dry Surfaces

No Adhesive is Needed • Never gets Gummy or Sticky • No Messy Cleanup

Not intended for High Pressure Systems

Instructions:

1. Clean large debris off tubing surface.
2. Peel back a short length of film from silicone tape before wrapping.
3. Begin wrapping directly over the repair area. Make 2-3 complete wraps while stretching tape at least twice its length to ensure the best fusion. The tighter Q-Wrap is wrapped, the quicker and stronger it fuses.
4. Continue by overlapping Q-Wrap onto itself by at least 50%, where $\frac{1}{2}$ the width is covered by the next wrap. This will ensure a proper seal.
5. Continue wrapping tape back and forth over repair allowing for at least one full inch in width on each side of repair while pulling tape tightly.
6. To complete, stretch the last wrap and overlap Q-Wrap completely onto itself. Continue pulling tight and cut.
 - Q-Wrap fuses immediately and is not reusable. Remember to completely overlap tape at the beginning and on the final wrap.
 - Visit our website for more information regarding Q-Wrap